

«Classic» Trombone case

Étui «Classic» pour trombone



«Classic» Trombone

Classic Tenor

REF. 3030 S

Classic Bass

REF. 3032 S

Color: Black - Coloris : Noir

- Covered case with a reinforced insert made of a single block of high resilience injected foam.
- Removable accessory pouches.
- Slide securely fitted in the foam cradle.
- Large flat front pocket.
- Available for Tenor and Bass trombone.
 - Étui houssé sur un calage monobloc renforcé, en mousse injectée de haute résilience.
 - Pochettes accessoires amovibles.
 - Coulisse clipsée dans un berceau de mousse.
 - Grande poche plaquée extérieure.
 - Existe pour Trombone ténor et basse.

«Softpack» Trombone case

Étui «Softpack» pour trombone



«Softpack» Trombone

Tenor

▪ Without pocket / sans poche

REF. 4030 S

▪ With pocket / avec poche

REF. 4030 SP

Bass

▪ Without pocket / sans poche

REF. 4032 S

▪ With pocket / avec poche

REF. 4032 SP

Jazz

▪ Without pocket / sans poche

REF. 4031 S

▪ With pocket / avec poche

REF. 4031 SP

Choice of 4 colors for the top shell: Black, Ultramarine blue, Mint, Terracotta. Lower shell: Black
Quatre couleurs pour le dessus: Noir, Bleu outremer, Menthe, Terracotta. Coque inférieure : Noir

- ABS shell
- 2 anti-slip backpack straps with security screw hooks
- Zipper
- Total suspension of the instrument in an injected foam cradle.
 - Coque en ABS
 - 2 Sangles sac-à-dos antidérapantes
 - Fermeture éclair
 - Totale suspension de l'instrument sur mousse injectée.